

# WATER BUTT OVERFLOW KIT

## INSTALLATION GUIDE



**a.** Locate desired position of overflow (min 50mm from any edge/corner of the water butt). Using a 29mm hole-saw or spade.

**b.** Place rubber washer over male thread and push this piece through the drilled hole from inside so that the thread protrudes out from the butt.



**c.** Fasten tank connector with locking nut. Hand tight only.



**d.** Screw snap on hose connector to male thread, ensuring rubber washer is in place.



Ecosure  
Efills Ltd  
Unit 1  
Whiting Way  
Melbourn, Royston  
SG8 6NA

Phone: 01763 261781  
Email: [sales@ecosure.co.uk](mailto:sales@ecosure.co.uk)  
Website: [www.ecosure.co.uk](http://www.ecosure.co.uk)

