



Ecosure
Etills Ltd
Unit 1
Whiting Way
Melbourn
Hertfordshire
SG8 6NA

Phone: 01763 261781
Fax: 01763 268409
Email: sales@ecosure.co.uk
Website: www.ecosure.co.uk



BRASS GARDEN TAP KIT





THANK YOU

Thank you for buying the Brass Garden Tap Kit. We hope you will be completely satisfied with your purchase.

IMPORTANT SAFETY INSTRUCTIONS

All Ecosure Water Butt and Water Tanks must be sited on a flat, level base.

- When fixing your tap or valve to the moulded outlets, start with 4 or 5 layers of PTFE tape and **DO NOT OVERTIGHTEN. Hand tighten only; do not use a spanner or wrench.**
- When using any power tools, be aware of others around you and wear suitable PPE (e.g. eye protectors and gloves).

Installation Notes:

a. If your tap does not sit straight you may have too much PTFE tap on the thread. Remove some from the reducer and try screwing the tap on again.

b. If water leaks out between the tap and reducer. You should put on more PTFE tap.

BRASS TAP INSTALLATION GUIDE

a. Wrap PTFE tap around the thread of the brass tap.



b. Screw on the supplied reducing nut (if required).



c. Wrap PTFE tap around the thread of the reducer.



d. Screw the complete tap kit into the threaded outlet of your tank.

**BEING CAREFUL NOT TO
OVERTIGHTEN.**

