



GUIDELINES FOR INSTALLING A DOWNPIPE DIVERTER

Ecosure
Efills Ltd
Unit 1
Whiting Way
Melbourn
Hertfordshire
SG8 6NA

Phone: 01763 261781
Email: sales@ecosure.co.uk
Website: www.ecosure.co.uk



THANK YOU

Thank you for buying our Standard Downpipe Diverter. We hope you will be completely satisfied with your purchase.

IMPORTANT SAFETY INSTRUCTIONS

All Ecosure Water Butts and Water Tanks must be sited on a flat, level base.

- Please leave at least a **50mm gap** all around the water butt. This will allow for the natural expansion of the water butt.
- When using any power tools, be aware of others around you and wear suitable PPE (e.g. eye protectors and gloves).

DOWNPIPE DIVERTER INSTALLATION GUIDE

a. Cut a 25mm hole to fit the downpipe connector.

This hole must be **40mm** from the top and any edge of the water butt.



b. Push the connector through the hole with the washer on the **INSIDE**



c. Tighten the nut on the outside by hand to form a seal.



d. Line up the diverter and mark a line below hose connection.



e. Using a hacksaw, cut this section from the downpipe.



f. Install the diverter into the downpipe. Push the cut downpipe into the diverter body.

If you don't have enough room to slide the downpipe, make a 2nd cut 30mm higher.



g. Measure and cut the diverter hose to length, keeping the pipe straight.



h. Push the flexible hose onto both connectors. A small amount of lubricant can help.

