ECOSURE PILLAR TANK (1275 LITRES)

Customer Guidelines



Thank you for purchasing an Ecosure 1275 Pillar tank. We hope that you are happy with your purchase.

INSTALLATION GUIDELINES

- Although your tank has been tested in accordance with our quality control procedures, please check it thoroughly to ensure that no damage has occurred in transit and report any damage within 48 hours of delivery.
- The tank must be sited on a flat, level concrete base.
- Please leave at least a 50mm gap all around the tank. This will allow for the natural expansion of the tank when full of water.
- Choose which threaded outlet you wish to use and drill out the plastic using a holesaw or a spade bit, being careful not to damage the outlet itself.
- When fixing a tap or a hose connector to a threaded outlet, use PTFE tape and DO NOT OVERTIGHTEN.
- Rainwater diverters can be installed approximately 40mm below the top of the tank. Please remember to keep the pipe running from the tank to the down-pipe level, to act as an overflow for the tank.





Etills Ltd, Unit 1 Whiting Way, Melbourn, Royston, SG8 6NA

Call 01763 261781 for further advice or information