

ECOSURE 800 LITRE PILLAR TANK

Customer Guidelines



Thank you for purchasing the Ecosure Pillar. We hope that you are happy with your purchase.

INSTALLATION GUIDELINES

- Although your tank has been tested in accordance with our quality control procedures, please check it to ensure that no damage has occurred in transit.
- The tank must be sited on a flat, level concrete base.
- Please leave at least a 50mm gap all around the tank. This will allow for the natural expansion of the tank when full of water.
- Choose which threaded outlet you wish to use and drill out the plastic, being careful not to damage the outlet itself.
- When fixing a tap or a hose connector to a threaded outlet, use PTFE tape and **DO NOT OVERTIGHTEN.**
- Rainwater diverters can be installed approximately 40mm below the top of the tank. Please remember to keep the pipe running from the tank to the down-pipe level, to act as an overflow for the tank.



Etills Ltd,
Unit 1 Whiting Way,
Melbourn,
Royston,
SG8 6NA



Call 01763 261781 for further advice or information